

brands you trust.



XLB - Lined Ball Valves



www.cranechempharma.com



XLB Lined Ball Valve Lower Torque - Smaller Actuators



Full Port XLB valves are also available in stainless steel construction with bodies in EN 1.4408 / ASTM CF8M material. Stainless steel valves are designed to maximize cleanliness and minimize areas where contamination could occur.





XLB Lined Ball Valve Innovative Stem Sealing System

Stainless steel lever

latching device minimizes possibility of accidental operation. Locking capability as standard. Made of stainless steel material ideal for corrosive environments.



Metal-to-metal contact

at the body joint ensures that no parts of the lining can be crushed or deformed because of forces within the piping system.

Wide conical plastic connection

designed to maintain total seal even under extreme thermal cycling.



Atmospheric seal innovative "pressure assisted" SX seal device provides the highest protection against fugitive emissions.

Anti blow-out integral ball and stem

retains positive control and minimizes the danger of stem/ball failures due to liner damage at wear points.



Locked in fluoroplastic liner

resists shrinkage and collapse, and permits vacuum applications.

Chemically modified PTFE (CMP) seats

provide greater pressure stability at higher temperatures than conventional PTFE.

ENHANCED DUAL SPECIFICATION DUCTILE IRON MATERIAL	
Standard / Grade	EN 1563 / JS 1049 ASTM A395 / 60-40-18
Chemical Requirements	C min. 3%, SI max. 2.5%, P max. 0.08%
Perlit Content	max.5%*
Spheroidal Graphite	min.90%*
Tensile Strength [N/mm ²]	min.415
Yield Strength [N/mm ²]	min.275
Elongation [%]	min. 18
Hardness [HB]	143-187
Impact Test [Joules]	min. 14 @ -20°C*
Impact Test [Joules] Single Valve	min. 11 @ -20°C*
*Requirement of PAS1085	Source: PAS 1085: 2008-0



XLB Lined Ball Valve Dynamic Body Joint Design

When valves are closed under pressure, the ball is able to float with line pressure and pressurize the downstream seat to further enhance the in-line seal. However, the stem will tend to tilt and can side load conventional packing, leading to potential wear and eventual leakage. The SX seal in the XLB valve moves in conjunction with the spherical portion of the stem, maintaining a constant seal.



Fig.1: In a conventional valve, moderate stem side loading can lead to significant emissions issues.

Other situations where side loading can occur during valve actuation include heavy manual operation, actuation loads, and misalignment, and abusive contact.

Fig.2:

The XLB valve's pressure assisted SX seal stays in constant contact with stem spherical seal surface to significantly reduce the chance of atmospheric leakage.



XLB dynamic body joint design retains pressure boundary during thermal cycles

The body assembly has metal-to-metal connection that offers resistance against forces that may be created in the pipework. This feature is designed to alleviate deformation and damage to the lining, even under pressure induced stresses. Also, the body joint sealing is provided with taper lining overlap, which is especially effective under high internal pressure and temperature variations.



www.cranechempharma.com



XLB Lined Ball Valve Options and Accessories

Material and Liner Options



Low Temperature

Carbon Steel Body

- All full port configurations available Low service temperatures below
- -20°F/-29°C
- Extremely cold environments below -20°F/-29°C

All sizes and configurations available



- Applications that cause potential electrostatic
 Complian with ATEX European
 - Complies with ATEX, European Directive 94/9/EC

Antistatic-PFA Lining



- All sizes and configurations available
- Halogen applications
- Service temperatures limited to 130°C/266°F

PVDF-Lining

Other Ball Valve Designs



Glass Pipe Design



Bottom Discharge Valve



Compact Ball Valve

- DN25-DN50 with and without flanges available Compact design adapted to the
- needs of glass piping systems
- Low weight and break torques
- DN25 (1")-DN150 (6") available Tank connection flanges through
- DN 250 (10") Allow efficient discharge of
- corrosive fluids from liquid tanks.
- DN25 (1")-DN80 (3") available
- All stainless steel construction Available with combined EN and ASME flange connections for maximum flexibility

Operator Options



Standard Locking Lever



Oval Handle



Stem Extension



Automated Valve

Flow

- Stainless steel for corrosive
 environments
- Lockable as standard
- Spring-loaded latching mechanism
- Optional for sizes up to DN40 (1 1/2")
- Stainless steel for corrosive environments
- Compact design discourages accidental operation
- Standard stem extensions in stainless steel
- Provides necessary clearance for operators in insulated pipeline installations
- Used with lever, gear or automated packages
- XLB valves can be automated with manual, pneumatic or electric actuators.
- Actuator mounting dimension in accordance with ISO 5211
- Low torque allows for economical automation solutions



Characterized Valve

• Available for all sizes

Characterization

- One piece ball and stem design of XLB provides more positive rotational control than 2-piece designs
- Offered with standard V port characterization or customized solutions



XLB Lined Ball Valve Applications

XLB valves offer economical solutions for the vast majority of chemical applications while maintaining the highest possible degree of performance in terms of in-line leakage and fugitive emissions.

They are commonly used within the following industries:

- Chlor-Alkali
- Industrial Inorganic Chemicals
- Metal and Mining
- Nitrogen and Phosphatic Fertilizers
- Petroleum Refining
- Pharmaceutical

Within these industries, XLB valves have superior performance in the following applications

- Chlorine
- Benzene
- Bromine
- Sulfuric Acid
- Nitric Acid
- Hydrochloric Acid
- Phosphoric Acid
- Sea Water



CRANE ChemPharma, Xomox® XLB Lined Ball Valve - Performance Chart

Visit our website, <u>www.cranechempharma.com</u>, to view these and other lined products, applications, brochures, certification, documents and more.



XLB Lined Ball Valve Other Lined Products from XOMOX



Fully lined sampling valves



Fully lined sight glass



Fully lined strainer and filters



In-line ball check valves



Y Pattern ball check valves



Vertical and horizontal poppet check valves



Spring assisted check valves



Swing check valves

LINED PLUG VALVES

BUTTERFLY VALVES

LINED



Stainless steel lined plug valves



3 Way lined plug valves



Lined plug valve with ISO 5211 mounting



Lined plug valves, PN 16, class 150 and 300



Fully PFA lined butterfly valves



Fully rated lined butterfly valves for off-shore applications

Visit our website www.cranechempharma.com for additional product info.

CRANE ChemPharma Flow Solutions™

XOMOX[®] Headquarters 4444 Cooper Road, Cincinnati, OH 45242, U.S.A. Tel.: (513) 745-6000 Fax: (513) 745-6086 XOMOX[®] International GmbH & Co. OHG Von-Behring-Straße 15, D-88131 Lindau/Bodensee Tel.: (49) 8382-702-0 Fax. (49) 8382-702-144

CP-XOMOX-XLB-BU-EN-TO-3/11

www.cranechempharma.com



ChemPharma Flow Solutions



brands you trust.

CRANE ChemPharma Flow Solutions Include: Pipe - Valves - Fitting - Actuators - Pumps



Crane Co., and its subsidiaries cannot accept responsibility for possible errors in catalogues, brochures, other printed materials, and website information. Crane Co. reserves the right to alter its products without notice, including products already on order provided that such alteration can be made without changes being necessary in specifications already agreed unless otherwise indicated. All trademarks in this material are property of the Crane Co. or its subsidiaries. The Crane and Crane brands logotype (DEPA®, ELRO®, Krombach®, PSI®, Resistoflex®, ResistoPure™, Revo®, Saunders®, and XOMOX®) are registered trademarks of Crane Co. or its subsidiaries. All rights reserved.

© 2011 CRANE Co., www.cranechempharma.com